



# Using MD engines to stream simulation output to the Client



FAST. FLEXIBLE. FREE.  
**GROMACS**

**NAMD**  
Scalable Molecular Dynamics



Amruthesh Thirumalaiswamy

# IMDv3 functionality in various MD engines

- **Source Code modifications**

- IMDv3 features were appended to existing code modules pertaining to IMDv2
- The IMDv2 code template was maintained and only changed where needed
- The modified source codes have been tested for consistency and against unchanged versions of the codebases.




- **IMDv3 functionality**

- IMDv3 features were added in accordance with the new protocol
- Functions and modules added -- provide the ability to stream (send) specific information
- Ability to control streaming settings through MD engine input configuration file

# Streaming Data



- Data is streamed and sent in the form of packets which contain a **header** and a **body**



- Value** sets the type of Message/information being sent in the body
- Length** sets the length of that information
- Simple messages like **IMD\_GO**, **IMD\_DISCONNECT**, **IMD\_KILL** do not have a body and have a zero length
- Others like **IMD\_FCOORDS** or **IMD\_VELOCITIES** have long array-like data within their bodies
- IMD\_HANDSHAKE** -- special case i.e. length variable contains the *IMD version* number

IMD Message Type	enum value
IMD_DISCONNECT	0
IMD_ENERGIES	1
IMD_FCOORDS	2
IMD_GO	3
IMD_HANDSHAKE	4
IMD_KILL	5
IMD_MDCOMM	6
IMD_PAUSE	7
IMD_TRATE	8
IMD_IOERROR	9
IMD_SESSIONINFO	10
IMD_RESUME	11
IMD_TIME	12
IMD_BOX	13
IMD_VELOCITIES	14
IMD_FORCES	15
IMD_WAIT	16

# Configuring MD engine input for streaming

- **IMD\_SESSIONINFO** -- special message packet, contains setting options for streaming process
- Settings configured by the user in simulation input file

## Header:


```
10 (int32) Value: Session info
7 (int32) Length: Number of configuration options in the body
```

## Body:

```
<val> (int8) Are time packets sent?
<val> (int8) Are IMD energy block packets sent?
<val> (int8) Are box packets sent?
<val> (int8) Are coordinate packets sent?
<val> (int8) Are coordinates wrapped into the simulation box?
| | | | | Meaningless if coordinates not sent!
<val> (int8) Are velocity packets sent?
<val> (int8) Are force packets sent?
```

- Similar input functionality available in other MD engines code packages

- As an example, NAMD uses an input configuration file that would look like ..




```
# IMD parameters

# standard IMD parameters
# IMDon streaming -- on or off
IMDon      yes
# IMDport -- port number to listen on
IMDport    8888
# IMDfreq -- frequency to send data
IMDfreq    1
# IMDwait -- wait for client to connect before starting simulation
IMDwait    on

# IMD version -- 2 for VMD and 3 for latest protocol
IMDversion 3
# IMD session info settings
# IMDsendPositions -- sending positions of entire system
IMDsendPositions      yes
# IMDsendEnergies -- sending energies and bonded, non-bonded and other contributions
IMDsendEnergies       yes
# IMDsendTime -- sending time information (time, dt, step)
IMDsendTime           yes
# IMDsendBoxDimensions -- sending box dimensions (lattice vectors a, b, c)
# If box dimensions are not defined, default unit box is sent
IMDsendBoxDimensions  yes
# IMDsendVelocities -- sending velocities of entire system
IMDsendVelocities     yes
# IMDsendForces -- sending forces on all atoms
IMDsendForces         yes
# IMDwrapPositions -- wrapping positions to box; applicable when IMDsendPositions is yes
IMDwrapPositions      yes
```

# Configuring MD engine input for streaming



- The input file in LAMMPS can be set with a line that takes care of various IMDv3 settings

```
## IMD settings
# https://docs.lammps.org/fix_imd.html
fix 2 all imd 8888 trate 1 version 3 unwrap off time on box on coordinates on velocities on forces on
```




- For GROMACS the mdp file is modified with requisite IMDv3 settings, which can then be assembled into a binary tpr using grompp


```
; IMD parameters
IMD-group          = System      ; group to send to IMD
IMD-nst            = 1          ; transmission rate to IMD
IMD-version        = 3          ; version of IMD protocol
IMD-time           = yes        ; if time information should be sent (time, dt, step)
IMD-box            = yes        ; if box dimensions should be sent (lattice vectors a, b, c)
IMD-coords         = yes        ; if coordinates should be sent
IMD-unwrap         = no         ; if coordinates should be unwrapped
IMD-vels           = yes        ; if velocities should be sent
IMD-forces         = yes        ; if forces should be sent
IMD-energies       = no         ; if energies should be sent
```



# Availability of Source Codes and Docker containers

## LAMMPS

-  [GitHub - ljwoods2/lammps: Public development project of the LAMMPS MD software package](#)
- <https://github.com/ljwoods2/lammps>




## NAMD

-  [GitHub - amruthesht/namd-3.0-IMDv3-patch](#)
- <https://github.com/amruthesht/namd-3.0-IMDv3-patch>

Patch with  
instructions





## GROMACS

-  [Files · imd-v3 · ljwoods2 / GROMACS · GitLab](#)
- [https://gitlab.com/ljwoods2/gromacs/-/tree/imd-v3?ref\\_type=heads](https://gitlab.com/ljwoods2/gromacs/-/tree/imd-v3?ref_type=heads)



## Docker Containers

-  [GitHub - Becksteinlab/streaming-md-docker: Docker images with MD packages that support streaming with IMD v3.](#)
- <https://github.com/Becksteinlab/streaming-md-docker>




# IMDClient – the receiver

- The receiver is any program capable of receiving data from the IMD stream
- IMDv2 used a VMD as a receiver



[GitHub - Becksteinlab/imdclient: Streaming analysis from running MD simulations.](#)

- **IMDClient** -- python package that is compatible with the IMDv3 protocol
  - built to receive and process incoming streaming data from producer (MD engine)
- Provides *infrastructure* to read data from the socket
  - Data is read from socket – stored in a temporary buffer
- Data from buffer is read into an object for further processing and analysis



# IMDClient – the receiver

- Contains a **IMDReader** class built upon MDAnalysis reader base class
  - Data from buffer read into MDAnalysis universe
- Data can be paired with different MDAnalysis functions to perform analysis



## IMDClient

- [GitHub - Becksteinlab/imdclient: Streaming analysis from running MD simulations.](https://github.com/Becksteinlab/imdclient)
- IMDclient is publicly available here: <https://github.com/Becksteinlab/imdclient>
- It is available via PyPI and can be easily installed with pip as follows:

```
pip install imdclient
```

- And can be done inside a virtual environment in conda

```
conda create --name imdclient  
conda activate imdclient  
pip install imdclient
```

This framework allows us to perform ***on-the-fly analysis***



# On the fly analysis

- **Producer:** MD simulation run on **NAMD** for a large system describing a lipid membrane with ions permeating through it (run on remote server)
- **Receiver:** IMDClient run on Jupyter Notebook with MDAnalysis to receive and perform in-situ **RMSF** and **RDF** analysis and provide a **live visualization** (run on remote server – separate core)